

## **LIFT MAINTENANCE**

No maintenance is required other than inspection for safety.

## **One Year Guarantee**

Every JARVIS product is inspected before leaving the factory. This product is warranted to be free of defects in material and workmanship. JARVIS will replace free of charge, with the same or like item of equal value any item found to have defects in materials or workmanship during the first 1 year of customer ownership with proof of purchase. Proof of purchase must be either original or clear copy of your receipt. Call 1-800-548-4239 for a return authorization number. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. Some parts made in China.

# **RESIDENTIAL #2 COMPLIFT** INSTRUCTION MANUAL



**COMPLIFT**

1-800-548-4239

A division of Jarvis Industries, Inc.

## Owner and/or Operator Responsibility

The owner and/or operator shall study the product instructions and retain them for future reference.

## Operation

The owner and/or operator shall have an understanding of the product and safety operating instructions before operating the LIFT. Safety information shall be emphasized and understood. If the operator is not fluent in English, the product and safety instructions shall be read to and discussed with the operator in the operator's native language by the purchaser/owner or his designee, making sure that the operator comprehends their contents.

## Maintenance

The LIFT shall be maintained in the accordance with the product instructions.

## Inspection

- (a) Visual inspection shall be made before each use of the LIFT by checking for abnormal conditions, such as cracked welds, leaks, and damaged, loose, or missing parts.
- (b) Other inspections shall be made per product operating instructions.
- (c) Each LIFT shall be inspected immediately if the lift is believed to have been subjected to an abnormal load or shock. It is recommended that this inspection be made by a manufacturer's or supplier's authorized repair facility.
- (d) Owners and/or operators should be aware that repair of this equipment may require specialized knowledge and facilities. It is recommended that an annual inspection of the LIFT be made by a manufacturer's or supplier's authorized repair facility and that any defective parts, decals, or safety labels or signs be replaced with manufacturer's or supplier's specified parts.

## Damaged Equipment

Any LIFT that appears to be damaged in any way, is found to be worn or operates abnormally **SHALL BE REMOVED FROM SERVICE UNTIL REPAIRED**. It is recommended that necessary repairs be made by a manufacturer's or supplier's authorized repair facility if repairs are permitted by the manufacturer or supplier.

## Alterations

Because of potential hazards associated with this type of equipment, no alterations shall be made to the products.

## Attachments and Adaptors

Only attachments and/or adaptors supplied by the manufacturer shall be used.



- Study, understand, and follow all instructions before operating this device.
- This is a lifting device only.
- Do not exceed rated capacity.
- Use 3/4" plywood for soft surfaces.
- Failure to heed these markings may result in personal injury and/or property damage.
- No alterations to the LIFT shall be made to this product.

2.

## INSTRUCTIONS FOR USE

*Two persons recommended for assembly.*

1. Assemble the four (4) legs into the sockets as shown in drawing. Secure with the bent pins and cotter pins.
2. Insert the two (2) telescoping beam support into the leg assemblies.
3. Install the bent pin so that the telescoping beam support is at it's lowest position.
4. With the leg assembly laying flat on the ground lift the beam socket end only and install the beam. Install bent pin. Install the trolley on the beam. Note orientation of socket. Repeat for the other leg assembly.
5. Install the chain hoist.
6. Check all bent pins and cotter pins.
7. Adjust height as required.
8. Assembly is complete.

